Heraeus

Technical Data Sheet



Product Type: Component Metallizations

Product Name: CL11-5100

Platinum Conductor

Description

CL11-5100 is a fritless platinum paste, which fires to a pure metal surface. CL11-5100 has a rheology suitable for screen printing.

Key Benefits

- Chemically resistant
- Fritless paste
- Can be used on zirconia or titania bodies

Typical Properties

Metal Type

Platinum

Resistivity

< 60 m Ω/\Box at 12 μ m fired film thickness

Viscosity

70 – 110 Kcps, Brookfield HAT #14 spindle and 6R utility cup at 10 rpm, 25 °C

Solids

84.5 ± 1.0 %

Recommended Processing Guidelines

Printing

280 – 325 mesh 0.5 mil emulsion

Drying

90 – 130 °C peak temperature Cycle time of 10 minutes

Firing

900 - 1200 °C peak temperature Dwell time of 9 - 11 minutes

Thickness

Dried: $16 - 18 \mu m$ Fired: $10 - 12 \mu m$

Thinner

RV-372

Warranty

Material guaranteed to meet specifications for 6 months from date of shipment.

Storage

Store in a dry location at 5 – 25 °C.

DO NOT REFRIGERATE.

Allow paste to come to room temperature prior to opening. Spatulate well before using, as settling may occur during storage.

Heraeus Electronics

Heraeus Deutschland GmbH & Co. KG Heraeusstraße 12 – 14 63450 Hanau, Germany www.heraeus-electronics.com

Americas

Phone +1 610 825 6050 electronics.americas@heraeus.com

Asia Pacific

Phone +65 6571 7649 electronics.apac@heraeus.com

China

Phone +86 53 5815 9601 electronics.china@heraeus.com

Europe, Middle East and Africa

Phone +49 6181 35 4370 electronics.emea@heraeus.com

The descriptions and engineering data shown here have been compiled by Heraeus using commonly-accepted procedures, in conjunction with modern testing equipment, and have been compiled as according to the latest factual knowledge in our possession. The information was up-to date on the date this document was printed (fatest versions can always be supplied upon requestly.) Although the data is considered accurate, we cannot guarantee accuracy, the results obtained from its use, or any natent information from its use, (indiess this is contractually and excitofility accred in advance). The data is sunnified on the condition that the user's shall conduct lests to determine materials suitability for or particular anotherisation.