# SOL9661B Series



### New Generation Front Side Silver Paste For PERC+SE

- Ultra-Fine-line screen printing
- Superior contact and Voc for SE PERC emitter
- Low laydown and high adhesion

The Heraeus SOL9661B series front side silver paste was specially designed for ULDE (Ultra Lightly Doped Emitter) plus SE (Selective Emitter). SOL9661B series is based on the glass chemistry upgraded from the last generation to offer high adhesion and extra protection on laser damaged area, combined with the latest improvement in organic vehicle system for UFL(Ultra-Fine-Line) printing. As confirmed by customers, SOL9661B has efficiency gain >0.05% in mass production.


SOL9661B has a wide firing window toward lower temperature side, which makes the series well-performed on PERC solar cells, meanwhile, superior UFL printing ability gives more space to customer to reduce laydown and improve efficiency. It is worth mentioning that the SOL9661B platform allows our R&D to offer solutions for different printing technology and emitter.

#### **KEY BENEFITS**

- Ultra-Fine-line screen printing
- Superior contact and Voc for SE PERC emitter
- Low laydown and high adhesion
- High Voc, extra protection on laser damaged Selective Emitter
- Low firing temperature and wide contact window can further reduce LeTID
- Perfect compatibility with multi Busbar printing
- Allow quick and efficient customization

#### SUPERIOR ULTRA-FINE-LINE PRINTABILITY

The SOL9661B is perfectly tailored for Ultra-fine-line printability for screen printing. It supports a finger geometry that can print defect-free through a less than  $26\,\mu m$  screen opening in high throughput mass production.




Same conditions on 480/11 – 26 µm opening

## UNIQUE PASTE CHEMISTRY DESIGNED FOR SELECTIVE EMITTER PERC CELL

Continued innovation from last generation, SOL9661B features a unique patent pending glass frit and silver combination, enabling the tolerance of Low Peak, wide firing temperatures and emitter protection. Driven by Ultra-Fine-Line, conventional paste will get lsc gain but FF drop, Heraeus SOL9661B series' exclusive inorganic platform continues to improve the contact performance, can achieve lsc and FF gain at the same time.

#### SOL9661B has Better Contact Performance than SOL9651B



#### TYPICAL PROPERTIES

#### Wafer types:

Mono crystalline PERC

Mono crystalline PERC with SE

Solid content:  $91 \pm 1\%$ Fineness of Grind (FOG):

■ 4th scratch: ≤ 12 μm

■ 50%: ≤8μm

#### Viscosity:

CPE-51 spindle (Brookfield): 40-110 kcps @ 1 RPM, 25°C

#### RECOMMENDED PROCESSING GUIDELINES

Single Print:  $480/11 \le 26 \mu m$  opening;

430/13 ≤ 28 µm opening


**Dual Print:**  $480/11 \le 26 \mu m$  opening;

 $430/13 \le 28 \mu m$  opening

**EOM thickness:** ≤ 15 µm EOM

**Drying:** Typically dried in an IR dryer with set points of 250-300°C in less than 20 seconds.

Firing: IR Furnace with Actual Wafer Peak Temperature at  $740-800^{\circ}\text{C}$  profile.



#### Storage:

Store in a dry location at 5°C-25°C. Stir well before using.

Contact your Application Engineering Team partner for individual advice.

EUROPE (GERMANY)
Heraeus Deutschland
GmbH & Co. KG
63450 Hanau

pv.hde@heraeus.com

ASIA (CHINA)

Heraeus Materials Technology

Shanghai Ltd.

201108 Shanghai Phone + 86 21 3357 5688 pv.hmts@heraeus.com AMERICA (USA)

Heraeus Precious Metals North America Conshohocken LLC/Heraeus Incorporated

19428 W. Conshohocken Phone +1 610 825-6050 pv.hpmc@heraeus.com

ASIA (JAPAN)
Heraeus K. K.
112-0012 Tokyo
Phone +81 3 6902 6564
pv.hkk@heraeus.com

ASIA (TAIWAN)

Heraeus Materials Technology Taiwan Ltd.

11492 Taipei Phone +886 2 2627 1111 pv.hmtt@heraeus.com

ASIA (SINGAPORE)

Heraeus Materials Singapore
Pte. Ltd.
639335 Singapore
Phone +65 6571 7888
pv.hmsl@heraeus.com

ASIA (KOREA)

Heraeus Korea Corporation

16506 Suwon-si (Gyeonggi-do) Phone +82 31 270 9428 pv.hmk@heraeus.com

Visit us online:

www.heraeus-photovoltaics.com www.heraeus-renewables.com www.heraeus-photovoltaics.cn www.heraeus-renewables.cn Follow us on LinkedIn!

