Condura[®].prime

Active Metal Brazed (AMB) Si₃N₄ Substrates DPIS⁽¹⁾



AMB-Si₃N₄ Substrate facts

- Silicon nitride ceramic
 Thickness: 0.25mm/0.32mm
- Active Metal Brazed Cu (99.96%)
 Thickness(2): 0.30mm/0.40mm/0.50mm
 0.60mm/0.80mm
- Asymmetric material combination is possible up to 0.60mm Cu thickness and a max. thickness difference of 0.10mm
- Single unit or master card
- Surface finish: Ag optimized for silver sintering Ni or NiAu, bare Cu selective (partial) plating possible

Key features

- Best in class reliability
- Enables thick Cu layers (e.g. 0.8 mm)
- Thinner ceramics vs. AIN possible for equal thermal resistance
- Thermal conductivity > 80 W/m.K of Si₃N₄ ceramic

Special features

- Best quality functional surfaces, e.g. Ag finish optimized for silver sintering technology
- Pre-applied sinter⁽³⁾ / solder
- Rimless Ag plating for more efficient and reliable surface area for bonding
- Special surface treatment to increase die shear strength

Main properties of Si₃N₄

	Rating	Unit
Bending strength $\sigma 0$	> 650	MPa
Fracture toughness	6 - 7	MPa·m ^{1/2}
Thermal conductivity (@ 20°C)	≥ 80	W/m-K
Coefficient of thermal expansion (20 °C - 500 °C)	2.6	10 ⁻⁶ /K
Young's modulus (@ 20°C)	> 280	GPa
Dielectric strength (@ 50 Hz)	15	kV/mm
Volume resistivity (@ 20°C)	> 10 ¹²	Ω·m

⁽¹⁾ Development Product Information Sheet, preliminary values


⁽²⁾ Different material combinations on request

⁽³⁾ Under development

Condura[®].prime


Design Rules AMB-Si₃N₄ DPIS⁽¹⁾

Metal free distance




Thickness Cu d [mm]	Min. metal free distance [mm]
0.30	+/- 0.30
-0.80	+/- 0.40

Structuring



Thickness Cu d [mm]	Min. metal free distance [mm]	Min. line [mm]	Min. pitch [mm]
0.30	0.50	0.50	1.00
0.40	0.70	0.70	1.40
0.50	0.70	0.70	1.40
0.60	1.00	1.00	2.00
0.80	1.00	1.00	2.00

Structuring tolerance



Thickness Cu d [mm]	Tolerance of structuring dimensions x, y [mm]
0.30	+0.20, -0.40
0.40	+0.30, -0.50
0.50	+0.30, -0.50
0.60	+ 0.40, -0.60
0.80	+0.40, -0.60

Sidewall of structured pattern + protruding length

Thickness Cu	D = sidewall of structured pattern (s)
d [mm]	+ protruding length (p*) [mm]
0.30 - 0.80	≤ ½ · d

Condura®.prime Design Rules AMB-Si₃N₄ DPIS⁽¹⁾

Mastercard / Single unit dimension & tolerances

Mastercard usable area	178mm · 127 mm
Single unit dimension*	≥ 15 mm · 15 mm
Tolerances	+0.2 / -0.05 mm

^{*}Smaller dimensions on request

Thickness tolerances					
Copper thickness (per each Cu-layer)	0.3 mm	0.4 mm	0.5 mm	0.6 mm	0.8 mm
Copper thickness tolerance (per each Cu-layer)	+10 / -30 μm	+10 / -30 μm	+55 / -55 μm	+55 / -55 μm	+55 / -55 μm
Ceramic thickness tolerance	± 50 μm				
Total thickness (Cu+Si ₃ N ₄ +Cu) tolerance	± 10 %				

Warpage behavior depends on specific layout, single unit size and material combination and can only be specified after initial sample preparation.

Thickness combinations



Si ₃ N ₄	Cu Thickness* (mm)				
Thickness (mm)	0.3	0.4	0.5	0.6	0.8
0.32	√	√	\checkmark	√	√
0.25	√	√	√	√	√

^{*}Others on request

Surface plating

Plating	Thickness (µm)
Ag full or Ag partial	> 0.2 - 1.0
Electroless Ni	3 - 7 (9% ± 2% P)
Immersion Au (ENIG, Au Class 1)	0.01 - 0.05
Immersion Au (ENIG, Au Class 2)	0.03 - 0.13

Au plating only applicable in combination with Ni

Condura[®].prime

Design Rules AMB-Si₃N₄ DPIS⁽¹⁾

Metal properties

Surface roughness*

 $R_a < 1.5 \mu m, R_z < 16 \mu m$

*Lower roughness on request

Copper peeling strength

> 9.8 N/mm

Customized surfaces for assembly process

Optimization of surface and assembly process parameters available or in development cooperation for:

- Silver sintering
- Solder wetting
- Heavy wire bondability

■ Condura[®] +

HET Academy R&D Application Center

Besides offering Assembly Materials, Bonding Wires and Metal Ceramic Substrates, Heraeus Electronics provides matching material solutions and R&D oriented partnerships to create individual solutions.

Heraeus Electronics offers:

- Reliable IATF 16949 certified supply of:
- ✓ Condura®.prime AMB-Si₃N₄ (active metal brazed Si₃N₄)
- ✓ Condura®.extra DCB-ZTA (zirconia-toughened alumina)
- ✓ Condura®.classic DCB-Al₂O₃ (direct copper bonded Al₂O₃)
- ✓ Engineering Services (Simulation, Prototype Design & Assembly, Testing and Qualification, Material Analysis)
- ✓ Pre-applied sinter / solder
- To be your competent **one-stop materials solutions partner!**

for example:

Americas

Phone +1 610 825 6050 electronics.americas@heraeus.com Asia Pacific

Phone +65 6571 7649 electronics.apac@heraeus.com

China

Phone +86 53 5815 9601 electronics.china@heraeus.com

Europe, Middle East and Africa

Phone +49 6181 35 4370 electronics.emea@heraeus.com

The descriptions and engineering data shown here have been compiled by Heraeus using commonly-accepted procedures, in conjunction with modern testing equipment, and have been compiled as according to the latest factual knowledge in our possession. The information was up-to date on the date this document was printed (latest versions can always be supplied upon request). Although the data is considered accurate, we cannot guarantee accuracy, the results obtained from its use, or any patent infringement resulting from its use (unless this is contractally and explicitly agreed in writing, in advance). The data is supplied on the condition that the user shall conduct tests to determine materials suitability for a particular application. The Heraeus logo, Heraeus and Condura® are trademarks or registered trademarks of Heraeus Holding GmbH or its affiliates. All rights reserved.