

Technical Data Sheet

THICK FILM MATERIALS

Product Type: End Terminations

Product Name: ET2001



Polymer Silver Plateable End Termination

Description

ET2001 is a dippable polymer based silver end termination. It contains a fast curing polymer system.

ET2001 is a Pb and Cd free Ni/Sn plateable polymer end termination designed to be compatible on multilayer ceramic chip capacitors (NPO and X7R bodies).

Key Benefits

- Ni and Sn plateable
- Solvent resistant
- Pb and Cd free

Typical Properties

Metal Type

Silver

Adhesion

Excellent Adhesion

Solvent Resistance

Excellent

Viscosity

40 – 60 Kcps Brookfield HBT

SC4 – 14 spindle, 6R utility cup at 10 rpm, 25 °C

% Solids

73.5 ± 1.5 %

Application

A blotting step can be used to control the amount of paste deposited on the chip body, if needed.

Recommended Processing Guidelines

Mixing

Material should be thoroughly mixed prior to use

Cleaning

Clean uncured resin with Acetone or similar solvent

Drying

120 °C for 10 minutes

Curing

185 °C for 60 minutes

Thinner:

V-521

Warranty:

Material guaranteed to meet specifications for 3 months from date of shipment.

Handling and Precautions:

Use in a well-ventilated area

Avoid contact with skin

Wash with soap and water

Storage:

Refrigeration a 5 °C required to maintain shelf life.

Allow paste to come to room temperature prior to opening.

Spatulate well before using, as settling may occur during storage.

3 months shelf life at room temperature

6 months shelf life when stored in refrigeration

Heraeus Electronics
Heraeus Deutschland GmbH & Co. KG
Heraeusstraße 12 – 14
63450 Hanau, Germany
www.heraeus-electronics.com

Americas
Phone +1 610 825 6050
electronics.americas@heraeus.com

China
Phone +86 53 5815 9601
electronics.china@heraeus.com

Asia Pacific
Phone +65 6571 7649
electronics.apac@heraeus.com

Europe, Middle East and Africa
Phone +49 6181 35 4370
electronics.emea@heraeus.com

The descriptions and engineering data shown here have been compiled by Heraeus using commonly-accepted procedures, in conjunction with modern testing equipment, and have been compiled as according to the latest factual knowledge in our possession. The information was up-to date on the date this document was printed (latest versions can always be supplied upon request). Although the data is considered accurate, we cannot guarantee accuracy, the results obtained from its use, or any patent infringement resulting from its use (unless this is contractually and explicitly agreed in writing, in advance). The data is supplied on the condition that the user shall conduct tests to determine materials suitability for particular application.