Heraeus

Technical Data Sheet



Product Type: Polymer Thick Film

Product Name: LTD5101

Blue Polymer Dielectric

Description

LTD5101 is a screen printable, single component and fast cure coating used for circuit protection and substrate insulation. This blue material, when properly cured, yields a chemically inert film which will not react with circuit components. LTD5101 provides excellent adhesion to a variety of substrate materials. This material is suitable for heater applications.

Key Benefits

- Wide range of curing conditions
- Excellent adhesion to multiple substrates
- Yields a chemically inert film
- Ideal for heater applications
- Compatible with Heraeus polymer conductors and resistors

Recommended Processing Guidelines

Printing:

 $280-325\ stainless$ steel mesh or nylon screen $0.5\ mil\ emulsion\ thickness$

Curing:

60 minutes @ 220 – 300 °C Recommended: 250 °C for 60 minutes

Thickness:

3 layers ≥ 40 µm cured film thickness

Thinner:

RV-252

Handling & Precautions:

Use in a well-ventilated area. In general, avoid contact with skin. Wash with soap and water. For cleanup of uncured material, RV-540 is recommended.

Warranty

Material guaranteed to meet specifications for 3 months from date of shipment

Storage

Store in a dry location at 5 - 25 °C

DO NOT REFRIGERATE.

Allow paste to come to room temperature prior to opening. Spatulate well before using, as settling may occur during storage.

SPECIAL NOTE:

Some of these materials may show resistance shifts due to thermal storage. Stability baking has been shown to minimize this behavior.



Technical Data Sheet

Blue Polymer Dielectric

Typical Properties

Dielectric Breakdown Voltage:

> 1000 volts/mil

Non-Volatile: (1Hr @ 150 °C)

82 - 84 %

Viscosity:

40 – 100 Kcps, Brookfield HBT, SC4-14 spindle @ 10 rpm, 25 °C

Heraeus Electronics Heraeus Deutschland GmbH & Co. KG Heraeusstraße 12 – 14 63450 Hanau, Germany www.heraeus-electronics.com Americas

Phone +1 610 825 6050 electronics.americas@heraeus.com

Asia Pacific

Phone +65 6571 7649 electronics.apac@heraeus.com

China

Phone +86 53 5815 9601 electronics.china@heraeus.com

Europe, Middle East and Africa Phone +49 6181 35 4370 electronics.emea@heraeus.com