

R2200 Series

Resistor System

Description

Series R2200 resistor system is a 10 Ω – 1k Ω, has been developed to meet high performance on alumina.

Key Features

- To be used with post-fired plating resistant 600 °C overglaze giving mean tolerance of resistance within ± 10 %
- Compatible with lead free series of Heraeus Ag contained conductors

Typical Fired Resistor Properties¹

Overglazed R2200 Series ^{2,5}	R2211 (WP14-23)	R2221 (WP15-05)	R2231 (WP15-23)
Resistivity ³ (Ω/□) with overglaze	10 ± 10 %	100 ± 10 %	1k ± 10 %
Temperature Coefficient of Resistance ⁴ TCR (ppm/K)	± 100	± 100	± 100
Dried Film Thickness (DFT) (µm)	25 ± 3	17 ± 3	17 ± 3

Legend

- Typical properties fired**
Results are based on laboratory test methods. For optimum results all materials should be fired in a profiled furnace supplied by dried, hydrocarbon-free and other contaminant-free air (PP-1).
- Processing conditions**
Termination: Heraeus lead free silver conductor composition C8729(H), pre-fired at 850 °C;
Substrate: 96 % alumina (Ceramtec, Rubalit 708S);
Printing: 325 mesh stainless steel screen with 30 µm emulsion, to a dried thickness of 17 ± 3 µm;
Firing resistor: 60 minute cycle (furnace entry to exit) to a peak temperature of 850 °C for 10 minutes for R2200 Series
Firing overglaze: See datasheet of IP 9036 A (green).
- Shipping specifications**
Resistor geometry: 1.25 mm x 1.25 mm
Post-fired resistor overglaze IP 9036 A (green) at 600 °C:
With double-wet-printing to a fired film thickness of 14 ± 3 µm.
Resistivity: The resistances indicated are the values after separate post-firing of IP 9036A on resistors at 600 °C.
- Temperature coefficient of resistance**
-55 °C to +25 °C and +25 °C to +125 °C.

The descriptions and engineering data shown here have been compiled by Heraeus using commonly-accepted procedures, in conjunction with modern testing equipment, and have been compiled as according to the latest factual knowledge in our possession. The information was up-to date on the date this document was printed (latest versions can always be supplied upon request). Although the data is considered accurate, we cannot guarantee accuracy, the results obtained from its use, or any patent infringement resulting from its use (unless this is contractually and explicitly agreed in writing, in advance). The data is supplied on the condition that the user shall conduct tests to determine materials suitability for particular application. The Heraeus logo and Heraeus, figurative mark are trademarks or registered trademarks of Heraeus Holding GmbH or its affiliates. All rights reserved.

R2200 Series

Resistor System

Typical Properties (Paste)
<ol style="list-style-type: none"> 1) Spatulate well prior to processing. When stored in a refrigerator allow paste to come to room temperature prior to opening, to avoid condensation. 2) Print through a 325 mesh stainless steel screen, 30 µm emulsion. Total screen thickness: 70 – 110 µm. 3) Level at room temperature for 5 – 10 minutes. 4) Dry at 150 °C for 10 minutes. Dried film thickness should be 17 ± 3 µm. 5) The electrical performance given in this data sheet refers to a 60 minutes firing cycle, with a peak temperature of 850 °C for 10 minutes.
Thinner
RV 372 or HVS 100

Typical Properties (Paste)	
Form	Pseudoplastic paste
Viscosity	20 – 50 Pas (25 °C, D = 100/s)
Coverage	tbd cm ² /g (DFT: 17 µm)
Shelf Life	6 months from date of shipment with correct storage (in a dry, cool (5 – 25 °C) and dark place with container tightly shut).
Compatibility	
Conductors	Ag C8729 AgPd C2160B AgPt C4729
Overglaze	IP 9036A

Americas
Phone +1 610 825 6050
electronics.americas@heraeus.com

Asia Pacific
Phone +65 6571 7649
electronics.apac@heraeus.com

China
Phone +86 53 5815 9601
electronics.china@heraeus.com

Europe, Middle East and Africa
Phone +49 6181 35 4370
electronics.emea@heraeus.com

The descriptions and engineering data shown here have been compiled by Heraeus using commonly-accepted procedures, in conjunction with modern testing equipment, and have been compiled as according to the latest factual knowledge in our possession. The information was up-to date on the date this document was printed (latest versions can always be supplied upon request). Although the data is considered accurate, we cannot guarantee accuracy, the results obtained from its use, or any patent infringement resulting from its use (unless this is contractually and explicitly agreed in writing, in advance). The data is supplied on the condition that the user shall conduct tests to determine materials suitability for particular application. The Heraeus logo and Heraeus, figurative mark are trademarks or registered trademarks of Heraeus Holding GmbH or its affiliates. All rights reserved.