
Heraeus



Condura®.prime Active Metal Brazed (AMB) Si₃N₄ Substrates

Silicon nitride offers excellent mechanical properties (high bending strength, high fracture toughness) and high thermal conductivity that makes it an ideal substrate material for high-reliable power electronics modules.

The outstanding mechanical robustness of $\mathrm{Si}_3\mathrm{N}_4$ enables brazing with thick Cu layers offering additional thermal capacity to dissipate load peaks. Thus baseplates become obsolete for certain applications.

AMB-Si₃**N**₄ **substrates** combine best mechanical robustness with excellent heat dissipation properties featuring very high power densities. Optimal performance and reliability can be achieved by using silver sintering, **Die Top System (DTS®)** and Cu bonding technology. This setup also enables utilizing the full potential of wide bandgap (WBG) semiconductors (SiC, GaN).

For your specific needs, we identify the optimal material combination from our broad product portfolio: metal ceramic substrates with functional surfaces optimized for our sintering, soldering and bonding solutions.

Key features of AMB-Si₂N₄

- Best in class reliability
- Enables thick Cu layers (e.g. 0.8 mm)
- Thinner ceramics vs. AIN achieving same thermal resistance
- Thermal conductivity > 80 W/m·K of Si₂N₄ ceramic

Special features

- Best quality functional surfaces, e.g. Ag finish optimized for silver sintering technology
- Pre-applied sinter / solder

Heraeus offers:

- Reliable IATF 16949 certified supply of Condura®.prime (as well as Condura®.classic & Condura®.extra)
- Engineering Services (Simulation, Prototype Design & Assembly, Testing and Qualification, Material Analysis)
- To be your competent one-stop materials solutions partner!

80 (mm/N) the strength of the



SAM

No copper delamination observable in ultrasonic testing

- Sinter paste LTS 338-28P2
- 0.32 mm AMB-Si₃N₄ with 0.3 mm Cu
- AMB functional surface 0.15 µm Ag

Shear strength

High shear strength due to the strong and reliable bonding of the silver sinter layer and optimized Ag finish of AMB-Si₂N_A

- Sinter paste LTS 338-28P2
- 0.32 mm AMB-Si₃N₄ with 0.3 mm Cu
- AMB functional surface 0.15 μm Ag


Bending test


No die delamination, high bending strength

- Sinter paste LTS 338-28P2
- 0.32 mm AMB-Si₂N₄ with 0.3 mm Cu
- AMB functional surface 0.15 μm Ag

Sintering conditions: 10 MPa, 230 °C, 3 min

Physical properties ideal for high-reliable modules using Ag sintering / Die Top System





Heraeus Electronics

Heraeus Deutschland GmbH & Co. KG Heraeusstraße 12-14 63450 Hanau, Germany www.heraeus-electronics.com

Japan

Phone +81 (3) 6902 6585 electronics.japan@heraeus.com

Americas

Phone +1 610 825 6050 electronics.americas@heraeus.com

Asia Pacific

Phone +65 6571 7677 electronics.apac@heraeus.com

Chin

Phone +86 21 3357 5457 electronics.china@heraeus.com

Europe, Middle East and Africa

Phone +49 6181 35 3627 electronics.emea@heraeus.com

The descriptions and engineering data shown here have been compiled by Heraeus using commonly-accepted procedures, in conjunction with modern testing equipment, and have been compiled as according to the latest factual knowledge in our possession. The information was up-to date on the date this document was printed (latest versions can always be supplied upon request). Although the data is considered accurate, we cannot guarantee accuracy, the results obtained from its use, or any patent infiringment resulting from its use (unless this is contractually and exploit, agreed in writing, in advance.) The data is supplied on the condition that the user shall conduct tests to determine materials suitability for particular application. The Heraeus logo, Heraeus and Condura® are trademarks or registered trademarks of Heraeus Holding GmbH or its affiliates. All rights reserved.