


## Infrared System cures Decorative Coatings on Insulated Containers

Decorative motifs on insulated containers, such as coffee pots or vacuum flasks, must be scratch-resistant, tough and ideally also dishwasher-proof. Alfi GmbH in Wertheim in Germany, a leading manufacturer of high-quality insulated flasks, has resolved this problem using an infrared system from Heraeus Noblelight.

Vacuum flasks from the Isobottle range are made from stainless steel with a painted coating. Decorative patterns are applied to the outside of the flasks using spot colours or screen-printing. Alfi applies the UV paints at six stations on a printing machine. When Alfi redesigned the base of its flasks and opted for a powder coating in order to make them dishwasher-proof, it became clear that the decorative coating would not pass the crosshatch test. In order to resolve this problem, Alfi decided to use heat as part of the post-curing process for the UV paint. Jürgen Hössel, head of assembly and service at Alfi, explains: "We opted for infrared radiation, because in comparison with hot air it has a far higher power density, responds very quickly and is therefore easy to control." The process parameters, such as the distance between flasks and the heat source, and the process times had to remain constant, so that all the flasks were processed under the same conditions. However, at the same time it was necessary to be able to adapt these parameters to suit the changing requirements.

The post-curing process begins when a robot places the printed flasks on a rotary plate between two infrared modules. The plate ensures that the products, which are rotationally symmetrical, are evenly heated. The two infrared lamps, which are positioned opposite one another, have a total rated power output of 6 kW. They are fitted with short wave, twin tube emitters which are arranged vertically in each module at a slight angle. Together with gold reflector on the emitters, this ensures that the heat is aimed directly at the product. The use of the infrared system after the UV curing process speeds up the chemical reaction (post-curing). In addition, the initial adhesion of the coloured film to the substrate is improved and the products can be processed or packed immediately. Jürgen Hössel is proud of the screen-printing machine: "The entire printing process is now fully automatic and has functioned perfectly right from the start. We have had a viewing panel installed and enjoy showing groups of visitors our infrared drying process."



### Features

- Post-curing of paints on insulated containers
- Evenly heating through rotation
- More rapid response time than conventional hot air oven
- Fast and efficient heat transfer
- Flexibel adaption to product requirements

### Technical Data

- Short wave twin tube infrared emitter
- Vertically positioned at a slight angle
- About 10 seconds to take effect

Germany  
**Heraeus Noblelight GmbH**  
Infrared Process Technology  
Reinhard-Heraeus-Ring 7  
63801 Kleinostheim  
Phone +49 6181 35-8545  
Fax +49 6181 35 16-8410  
hng-infrared@heraeus.com  
www.heraeus-noblelight.com/infrared

USA  
**Heraeus Noblelight America LLC**  
1520C Broadmoor Blvd.  
Buford, GA 30518  
Phone +1 678 835-5764  
Fax +1 678 835-5765  
info.hna.ip@heraeus.com  
www.heraeus-thermal-solutions.com

Great Britain  
**Heraeus Noblelight Ltd.**  
Clayhill Industrial Estate  
Neston, Cheshire  
CH64 3UZ  
Phone +44 151 353-2710  
Fax +44 151 353-2719  
ian.bartley@heraeus.com  
www.heraeus-infraredsolutions.co.uk

China  
**Heraeus Noblelight (Shenyang) LTD**  
2F, 5th Building 5  
No. 406, Guilin Rd, Xuhui District  
200233 Shanghai  
Phone +8621 3357-5555  
Fax +8621 3357-5333  
info.hns@heraeus.com  
www.heraeus-noblelight.cn