

TECHNICAL SPECIFICATION

Master Alloy: H-JSBR

Suitable karatage :		Brass	Colour	:	Yellow
Nickel Content :		0 %	Silver Content	:	0 %
Palladium Content:		0 %	Platinum Content	t :	0 %
Hardness :		72 HV			
Applications :		Suitable for loss wax casting, torch melting			
Advantages :	•	High fluidity, less porosity			

Recommended Casting Parameters:

Metal Casting Temperature : 1100 - 1120°C

: 530 - 630 °C **Investment Temperature** (Vacuum-assisted Casting)

> : 430 - 530 °C (Centrifugal Casting)

Quenching Time : 15 - 25 minutes

Technical Advice:

- 1. To avoid oxidation, the alloys must be covered with inert gas or yellow flame during casting.
- 2. Not more than 30 % of old material should be used for recasting.
- 3. The old material must be pickled in dilute sulfuric acid (10 %) for 15-20 minutes to remove the oxide, followed by tumbling to remove the investment powder residue.
- 4. The sprue should be placed at the thickest position. Additional sprue must be applied if necessary. Fluted sprue is preferred to avoid any turbulence.

Remarks: The information is for your reference only. The parameters should be adjusted according to the particular casting conditions. If you have any technical questions, please do not hesitate to contact us.

Kowloon, Hong Kong Tel: (852) 2159 5960 Fax: (852) 2773 1090 紅磡營業部: 賀利氏有限公司 香港九龍紅磡 崇安街 18 號 半島廣場 2111-3 室

電話: (852) 2159 5960 傳真: (852) 2773 1090