

TECHNICAL SPECIFICATION

Master Alloy: P-900

Suitable karatage :	Brass	Colour : Red
Nickel Content :	0 %	Silver Content : 0 %
Palladium Content:	0 %	Platinum Content: 0 %
Hardness :	66 HV	
Applications :	Suitable for loss wax casting, torch melting, use with Silver	
Advantages :	High fluidity, less porosity	

Recommended Casting Parameters:

Metal Casting Temperature : 1120 - 1150°C

Investment Temperature : $530 - 630 \, ^{\circ}\text{C}$ (Vacuum-assisted Casting)

> : 430 - 530 °C (Centrifugal Casting)

Quenching Time : 15 - 25 minutes

Technical Advice:

1. To avoid oxidation, the alloys must be covered with inert gas or yellow flame during casting.

- 2. Not more than 50 % of old material should be used for recasting.
- 3. The old material must be pickled in dilute sulfuric acid (10 %) for 15 20 minutes to remove the oxide, followed by tumbling to remove the investment powder residue.
- 4. The sprue should be placed at the thickest position. Additional sprue must be applied if necessary. Fluted sprue is preferred to avoid any turbulence.

Remarks: The information is for your reference only. The parameters should be adjusted according to the particular casting conditions. If you have any technical questions, please do not hesitate to contact us.

Tel: (852) 2675 1200 Fax: (852) 2682 3220 總公司: 賀利氏有限公司

香港新界粉嶺安樂村 安全街 30 號 賀利氏科技中心

電話: (852) 2675 1200 傳真: (852) 2682 3200 **Hunghom Sales Office:** Heraeus Ltd.

Rm. 2111-3, Peninsula Square 18 Sung On Street, Hunghom

Kowloon, Hong Kong Tel: (852) 2773 1733 Fax: (852) 2773 1090 紅磡營業部: 賀利氏有限公司 香港九龍紅磡 崇安街 18號

半島廣場 2111-3 室 電話:(852) 2773 1733 傳真: (852) 2773 1090