

TECHNICAL SPECIFICATION

Master Alloy: S-510

Suitable karatage:	14K (Easy)	Colour : White
Nickel Content :	16.38 %	Silver Content : 37.45 %
Palladium Content:	0 %	Platinum Content: 0 %
Applications :	Making 14K Easy solder for white gold	
Advantages :	Ease to use, high fluidity, less porosity	

Recommended Application Parameters:

Suggested Gold Content in Solder: 58.33% Alloy Melting Temperature : 14K / 742 °C

Technical Advice:

- 1. The melting temperature of the solder varies according to the alloy composition.
- 2. The recycled alloy should not be used for soldering purpose.
- 3. Appropriate amount of flux should be added during soldering.
- 4. The metal pieces should be well designed for soldering.
- 5. Two common methods of soldering are listed as reference:
 - Appropriate amount of solder was put on the joint, heat up to the joint until the solder melts a. and flows into the joint.
 - The fluxed joint is heated to appropriate temperature, then put the solder to the joint for b. soldering.

Remarks: The information is for your reference only. The parameters should be adjusted according to the particular casting conditions. If you have any technical questions, please do not hesitate to contact us.

Fax: (852) 2682 3220

Rm. 2111-3, Peninsula Square 18 Sung On Street, Hunghom

Kowloon, Hong Kong Tel: (852) 2159 5960 Fax: (852) 2773 1090 紅磡營業部: 賀利氏有限公司 崇安街 18 號 半島廣場 2111-3 室

電話: (852) 2159 5960 傳真: (852) 2773 1090