

## TECHNICAL SPECIFICATIONS

Master Alloy: H-6606

Suitable karatage :	10/14/18K	Colour :	White
Nickel Content :	20 %	Silver Content :	0 %
<b>Palladium Content:</b>	0 %	<b>Platinum Content:</b>	0 %
Hardness :	170 HV (14K)		
Applications :	Suitable for loss wax casting		
Advantages :	Less porosity, high re-casting rate		

## Recommended Casting Parameters:

: 10K / 1080 °C, 14K / 1045 °C, 18K / 1010 °C Metal Casting Temperature **Investment Temperature** : 530 – 660 °C (Vacuum-assisted Casting)

> :  $450 - 550 \, ^{\circ}\text{C}$ (Centrifugal Casting)

**Quenching Time** : 15 - 25 minutes

## Technical Advice:

- 1. To avoid oxidation, the alloys must be covered with inert gas or yellow flame during casting.
- 2. Not more than 50 % of old material should be used for recasting.
- 3. The old material must be pickled in dilute sulfuric acid (10 %) for 15-20 minutes to remove the oxide, followed by tumbling to remove the investment powder residue.
- 4. The sprue should be placed at the thickest position. Additional sprue must be applied if necessary. Fluted sprue is preferred to avoid any turbulence.

5.

Remarks: The information is for your reference only. The parameters should be adjusted according to the particular casting conditions. If you have any technical questions, please do not hesitate to contact us.

賀利氏有限公司 香港新界粉嶺安樂村 安全街 30 號 賀利氏科技中

總公司:

電話: (852) 2675 1200 傳真: (852) 2682 3220

**Hunghom Sales Office:** Heraeus Ltd.

Rm. 2111-13, Peninsula Square 18 Sung On Street, Hunghom Kowloon, Hong Kong Tel: (852) 2773 1733 Fax: (852) 2773 1090

紅磡營業部: 賀利氏有限公司 香港九龍紅磡 崇安街 18 號 半島廣場 2103 室

電話: (852) 2773 1733 傳真: (852) 2773 1090